



# FANTASY ZONE (834-5939) (834-5939-01) (833-5981-01)

COIN/CREDIT OPTION SWITCH SETTING	DIP SWITCH #1							
	1	2	3	4	5	6	7	8
1 COIN 1 CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN 2 CREDITS	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN 3 CREDITS	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
1 COIN 4 CREDITS	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
1 COIN 5 CREDITS	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN 6 CREDITS	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
2 COINS 1 CREDIT	OFF	ON	ON	OFF	OFF	ON	ON	OFF
2 COINS 2 CREDIT	ON	ON	ON	OFF	ON	ON	ON	OFF
2 COINS 3 CREDIT	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
2 COINS 3 CREDITS	ON	OFF	OFF	ON	ON	OFF	OFF	ON
2 COINS 1 CREDIT	OFF	ON	OFF	ON	OFF	ON	ON	ON
2 COINS 2 CREDITS	ON	OFF	ON	ON	OFF	ON	ON	ON
2 COINS 3 CREDITS	OFF	OFF	ON	ON	OFF	ON	ON	ON
2 COINS 4 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
2 COINS 5 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
2 COINS 6 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
1 COIN 1 CREDIT	ON	OFF	ON	ON	ON	ON	ON	ON
2 COINS 2 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
3 COINS 3 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
4 COINS 4 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
5 COINS 5 CREDITS	ON	ON	ON	ON	ON	ON	ON	ON
1 COIN 1 CREDIT	OFF	ON	ON	ON	OFF	ON	ON	ON
2 COINS 3 CREDITS	OFF	ON	ON	ON	OFF	ON	ON	ON
FREE CREDIT	ON	ON	ON	ON	ON	ON	ON	ON

1	A	GND
2	B	GND
3	C	COP SYNC
4	D	GREEN
5	E	SPEAKER (-)
6	F	NOT USED
7	G	NOT USED
8	H	2P START
9	I	1P START
10	J	NOT USED
11	K	NOT USED
12	L	NOT USED
13	M	2P LEFT
14	N	2P RIGHT
15	O	2P UP
16	P	2P DOWN
17	Q	NOT USED
18	R	2P WEAPON 2
19	S	2P WEAPON 1
20	T	NOT USED
21	U	NOT USED
22	V	COIN METER 2
23	W	+12V
24	X	+5V
25	Y	+5V
26	Z	GND
27	AA	GND
28	AB	GND



SUPPLY VOLTAGES & CURRENT	
VOLTAGE	CURRENT
DC 5V	7.5A
DC 12V	1.0A

OPTION SWITCH SETTING	DIP SWITCH #2							
	1	2	3	4	5	6	7	8
TABLE	OFF							
UPRIGHT	ON							
ATTRACT SOUND		OFF						
		ON						
3			OFF					
4			ON					
5			OFF					
250			ON					
\$ 5000, 20000, 50000, 100000				OFF				
EXTRA \$ 10000, 50000, 100000				ON				
\$ 15000, 70000, AND 150000				OFF				
\$ 20000, 100000, EVERY 200000				ON				
EASY					OFF			OFF
MEDIUM					ON			ON
HARD						OFF		OFF
HARDEST						ON		ON

# パワーアップ・パーツ

## Fantasy Zone

### スピードアップ・パーツ



- ビックウィング (BIG WINGS) ちよつと速くなる
- ジェットエンジン (JET ENGINE) 速くなる
- ターボエンジン (TURBO ENGINE) とても速くなる
- ロケットエンジン (ROCKET ENGINE) すごく速くなる

### ウエポン 1 WEAPON 1 (WEAPON 1 ボタンで使用する)



- ワイドビーム (WIDE BEAM) ワイドなビーム砲
- レーザービーム (LASER BEAM) レーザー砲
- 7ウェイショット (7 WAY SHOT) 7方向に撃てる機銃

### ウエポン 2 WEAPON 2 (WEAPON 2 ボタンで使用する)




- ツインボン (TWIN BOMBS) ノーマル爆弾を2発連続で落せる
- スマートボン (SMART BOMB) 画面上の敵、全てにダメージを与える爆弾
- ファイアーボン (FIRE BOMB) 横方向の基地を全て破壊できる爆弾
- ヘビーボン (HEAVY BOMB) 縦方向の基地を全て破壊できる爆弾

))))))))) 基地レーダーの説明 ()))))))))  
 (画面に見えている基地(破壊した基地)残っている基地)



©SEGA 1986  
H-52163



## Fantasy Zone

100% (基地) を10回破壊すると、敵のボスが登場!  
 敵のボスをやっつけて、次のエリアへ進もう!  
 {}}}} パワーアップの方法 {}}}}  
 敵を破壊すると、コインが出現。それを集めて貯金を増やそう!  
 (貯金) をとるとパーツ・ショットのシーンへ……  
 貯金でパワーアップ・パーツを買って下さい。  
 (SEL) をとるとパーツ・セレクトのシーンへ……  
 使用するパーツを、持っている中から選んで下さい。

ウエポン 1 WEAPON 1  
 ウエポン 2 WEAPON 2  
 パーツ・セレクト



©SEGA 1986  
P-52163

SEGA  
 ファンタジーゾーン  
 FANTASY ZONE  
 No. 21163