



An exciting new game from JALECO in which the hero invades the bodies of the enemies as he sets out upon a dangerous adventure in search of the special keys needed to unlock the secret hideaway where the lovely Miss Darling is being held.


ENERGY GAUGE -

for the Spirit

PLAYER'S CHARACTER pulses with a colorful outline.

ENERGY GAUZE-


for the player's character whose body the Spirit is possessing.



ENEMY CHARACTERS

The Spirit must choose to invade the body of any one of the enemy characters.

BONUS ITEMS



CAST OF CHARACTERS











For the Spirit to invade an enemy's body, descend on the enemy and press either button.

BONUS ITEMS





FLASH which annihilates all the enemies on the screen.



CAPSULE which gives an extra life.



ENERGY ELIXIR which adds 2-20 to the Energy Gauge.



MAGIC KEY which is to open the room where Miss Darling is being held.



BONUS POINTS of 100-50,000.

DIP SWITCH #1

1 COIN 1 CREDIT

AVENGING SPIRIT


OFF OFF OFF OFF

6

EDGE CONNECTOR DIAGRAM (EDGE CONNECTOR OF JAMMA SPECS.)

COMPONENT SIDE	SOLDER SIDE			
GND	1	A	GHD .	
. GND —	2	В	GND	
HEADPHONE L&R (-)				
+51	3	C	+51	
+57	4	D	+57	
	5	Е		
+12V	6	F	+124	
KEY TO PREVENT	7	Н	KEY TO PREVENT	
ERRONEOUS INSERTION			ERRONEOUS INSERTION	
COIN HETER #1	8	J	COIN HETER #2	
	9	. X		
SPEAKER 1 (+) -	10	L	SPEAKER 1 (-)	
HEADPHONE L (+)				
	11	Н		
VIDEO RED	12	Н	VIDEO GREEN	
VIDEO BLUE	13	P	VIDEO SYNC	
VIDEO GHD	14	R	SERVICE SV	
	15.	. S		
COIN SV #1	16	Т	COIN SV #2	
1P START	17	. IJ	2P START	
1P UP	18	. V	2P UP	
IP DOVN	19	V	2P DOVK	
1P LEFT	20	X	2P LEFT	
1P RIGHT	21	Y	2P RIGHT	
1P PUSH 1	22	2	2P PUSH 1	
1P PUSH 2	23	ä	2P PUSII 2	
1P PUSH 3	24	Ь	2P PUSII3	
	25	С		
	26	d		
GND	27	e	GND	
GND	28	f	GND	

SPEAKER 2 (+)	1	2	SPEAKER 2 (-)	
HEADPHONE R (+)			*	



AVENGING SPIRIT

For monaural volume control, adjust the left volume.

	1 COIN	2 CRECITS	NO	OFF	OFF	OFF				
	1 COIN	3 CREDITS	OFF	ОН	OFF	OFF				
	1 COIN	4 CREDITS	NO	ОН	OFF	OFF				
	1 COIN	5 CREDITS	OFF	OFF	ОН	OFF				
FIRST	1 COINS	6 CREDITS	ИО	OFF	ОН	OFF.				
COINCHUTE	2 COINS	1 CREDIT	OFF	ON	ОН	OFF				9
	3 COINS	1 CREDIT	OH	OH	ON	OFF				
	4 COINS	1 CREDIT	OFF	OFF	OFF	ОН				
	2 COINS	3 CREDITS	ИО	OFF	OFF	ON	100			
1 C 1 C	1 COIN	1 CREDIT					OFF	OFF	OFF	OFF
	1 COIN	2 CREDITS					ON	OFF	OFF	OFF
	1 COIN	3 CREDITS				He W.	OFF	ON	OFF	OFF
	1 COIN	4 CREDITS					ОН	ИО	OFF	OFF
	1 COIN	5 CREDITS					OFF	OFF	ON	OFF
	1 COIN	6 CREDITS				N-Y	ОН	OFF	ON	OFF
	2 COINS	1 CREDIT					OFF	ОН	ОИ	OFF
	3 COINS	1 CREDIT					ИО	ON	ОН	OFF
	4 COINS	1 CREDIT	18 1				OFF	OFF	OFF	ОИ
	2 COINS	3 CREDITS					ON	OFF	OFF	ОН
FREE PLAY			ОН	ON	ОН	ON	ОИ	ОН	ИО	ОН

DIP SWITCH #2

Sales Lines	and the state of	1	2	3	4	5	6	7	8
SCREEN DISPLAY	HORHAL (OR REVERSE)	OFF							
	REVERSE (OR NORHAL)	ОН						STEE	
NI DHUOZ	NECESSARY		ОН						
ATTRACT HODE CONTINUE	UNNECESSARY		OFF						
CONTINUE	YES			OFF					
	NO			ON					elusor
DIFFICULTY LEVEL HARD HARDER	EASY				OFF	ОИ			
	NORMAL				OFF	OFF			
	HARD				ON	OFF			
				NO	ОН				
MODEL	UPRIGHT						OFF		
	TABLE						ОН		
HOT. USED	KEEP IN "OFF"	7					1	OFF	
TEST HODE	YES					112			HO !
	110		1	:					OFF